
## "Royal" PEE WEE Viewer



TO FILL

Dip squirt section only of PEE WEE (marked Pat. Pend.) into water. Keep LENS OUT of water. Press down on lever as shown by arrow in illustration and release, permitting suction to take place — OR — hold lever down as you insert in water, then release.

DEFORE victim looks thru lens, instruct him to hold viewer UP to the light (with picture ABOVE level of lens) and then . . . turn crank for action.

If hole becomes clogged, insert point of fine needle. Do not enlarge hole.

PLEASE NOTE:—To make simple adjustments, clean lens, etc., REMOVE ONLY the BACK COVER (with picture).