INSTRUCTIONS

OIL BEFORE USING. One drop light machine oil inside the movement assembly and one drop on the small gear in back.

Use standard T4 or C7 FROSTED lamp. When in place the filament of the lamp should be in direct line with the opening in the light housing. Project from a distance of 6 to 12 feet.

To thread film turn handle slightly so prongs DO NOT project thru film track. Pull back hinged film gate and insert film UPSIDE DOWN with shiny side toward lamp. Turn handle slowly till prongs mesh in film perforations. Focus by moving projection tube with a TURNING motion till picture shows to best advantage.

Turn handle clockwise at whatever speed is desired Interesting effects may be had by turning handle backwards (counter-cloc wise).

FOR BEST RESULTS

Use Trojan Cycle-Action films. They are specially drawn and animated for use on this projector. As a result they are not only clearer and sharper but give you more action than you get in 10 feet of ordinary film.