



The diagram shows the viewer "Threaded" and ready for use.

LOADING

Remove empty special spool, place your loaded 50 ft. spool of film on the spindle J with film coming off in a clockwise direction. Pass on right side of C and through picture gate D - on the side away from the eyepiece. Then over pulley G making sure that one of the film sprocket holes engage in tooth E. Thence down between 2 pillars H and then on to special spool which is solely for use in the CINEVUE.

Slip back catch K and put end of film on to spool slot - shut catch K. Fit door, press side to fit in to position. Turn handle clockwise for animation view through eyepiece F. Focus is fixed but frame adjustment can be made by sliding bar L up or down.

TO REWIND

When film has been viewed, press end of spindle J and turn handle in reverse (anti-clockwise) direction. There is no need to remove viewer door until after the film has been rewound or when you wish to reload.

SPECIAL NOTES

1. The film path through the viewer is so designed as to keep the emulsion side of the film away from the stationary surfaces.
2. You can only view a well defined picture if the definition of the image on the viewed film is correspondingly sharp.